



Triggers/Timers

Main window:




Basic functions:




Triggers


- To activate the trigger, it is necessary to check the box next to number of trigger:




- Then select the type of triggering the trigger.




- Faling Edge** - Trigger triggering on the falling edge of the impulse, i.e. when passing from the upper state ("1") to the lower state ("0").




- Rising Edge** - Trigger triggering on the rising edge of the impulse, i.e. when passing from the lower state ("0") to the upper state ("1").



- After tripping, you can select the controller's output



- You can also choose to start the necessary procedure for triggering the trigger



Timers

- To activate the timer , it is necessary to check the box next to number of timer:




- After activating the timer, it is necessary to select the operating output of the controller




- You must select the duration of the output pulse and the length of the pause. Values are set in ms:

Timer 0 schedule



Timer 1 schedule



From:

<http://cnc42.com/> - myCNC Online Documentation



Permanent link:

http://cnc42.com/mycnc/triggers_and_timers

Last update: **2018/08/17 09:58**