


Start/Stop Setup

Additional information on Program Stop and the associated PLC procedures is available here: [Stop/End program button commands](#).

This article is designed to introduce the reader to the basic setup process of the Start/Stop procedure in myCNC settings.



Upon opening **CNC Settings > Preferences > Start/Stop**, the following screen is presented to the user:

The screenshot shows the "Start/Stop" configuration screen within the "Preferences" section of the "CNC Settings".

Top Navigation: The top bar includes icons for SYS, PLC, Info, Support, Camera, Cutchart, and Config, along with a "SAVE" button.

Left Sidebar (CNC Settings):

- Axes/Motors
- Inputs/Outputs/Sensors
- Network
- Motion
- PLC
- G-codes settings
- DXF import settings
- Macro List
- Macro Wizard
- Probing Wizard
- Preferences
 - Common
 - Start/Stop** (highlighted)
 - Shape Library Settings
- Screen
- Work Offsets
- Parking Coordinates
- Technology
- Camera
- 5 axes RTPC
- Panel/Pendant
- Hardware
- Advanced


Right Panel (Start/Stop Configuration):

- Cutting ON commands:** M20; M71; M03;
- Cutting OFF commands:** M21; M74; M05;
- Soft stop time,s:** 0.05
- Limit stop time,s:** 0.05
- Deceleration time, If "Stop" pressed:** Not defined
- After Stop Handler:** On Start
 - Check Soft Limits for the full toolpath:**
 - Toolpath Position checking, axes:** x x y x z x a x b x c x u x v
 - Current position & Toolpath position should be equal in given axes:**
- Goto Toolpath Position for axes:**
 - Cutting/Spindle ON & tool moves to toolpath position on Start for given axes:** Direct Move
 - Position:** 10
 - Speed:** 6000
- Lift Height:** 10
- Move-to-Toolpath speed:** 6000
- Current position as Start (*Disabled by default):**
- Reset work Position on "Reset-NC", "Tie" pressed:**

On Start behaviour

A common scenario with mill and plasma machines is having to move the plasma torch or any other working tool away from the cutting point in the middle of running a program, for cleaning/inspection/etc. In order to continue the cutting process smoothly after having stopped the machine and moved the working tool, the **On Start** section of the Start/Stop menu can be used to properly describe the behaviour of the machine when it is started again from the middle of the program.

The Check Soft Limits for the full toolpath toggle specifies whether the user wants to check the entire program for issues with soft limits (program work position going outside of soft limits) before starting the program. If the toggle is set to ON, and there are issues with the soft limits present, the program will not start. This setting is not recommended for extremely large programs, as it takes a lot of time to run the check. Programs under 10 000 lines of code are best suited for this process.



The behaviour of the machine with all the flags turned OFF is to simply continue cutting straight from the the point to which the working tool has been moved, as if it was still at its original position. This can lead to issues with cutting, since this effectively fails to cut the particular part at which the machine has been stopped. In order to correct this, two options are present.

- **OPTION 1:** Block the machine from starting up again if the new start point for the cut is not the same as the stop point.
- **OPTION 2:** After the machine has been stopped and move, automatically move it back to the original stop position before attempting to cut again.

NOTE: Only one option can be chosen for each given axis

Option 1: Block the machine from running

In order to block the machine from running if its new start position is different from its stop position, the user can select the particular axes for the machine to check before running. In the example below, the x- and y-axes have been selected to check their position before attempting to move again.

SYS
PLC
Info
Support
Camera
Cutchart
Config

SAVE

CNC Settings

Axes/Motors

Inputs/Outputs/Sensors

Network

Motion

PLC

G-codes settings

DXF import settings

Macro List

Macro Wizard

Probing Wizard

Preferences

Common
Start/Stop
Shape Library Settings

Screen

Work Offsets

Parking Coordinates

Technology

Camera

5 axes RTCP

Panel/Pendant

Hardware

Advanced

Cutting ON commands

Cutting OFF commands

Soft stop time,s

Limit stop time,s

After Stop Handler

On Start

Check Soft Limits for the full toolpath

Toolpath Position checking, axes

Goto Toolpath Position for axes

Lift Height

Move-to-Toolpath speed

Current position as Start ((*)Disabled by default)

Reset work Position on "Reset-NC", "Tie" pressed.

M20; M71; M03;

M21; M74; M05;

0.05

0.05

Deceleration time, If "Stop" pressed

Not defined

x y z a b c u v

Current position & Toolpath position should be equal in given axes

x y z a b c u v

Cutting/Spindle ON & tool moves to toolpath position on Start for given axes

Direct Move

10

6000

This will check the axes and, if any position values for each selected axis are different after the move, will stop the program when the Run button is pressed, as seen in the image below:


The screenshot shows a CNC control interface with the following elements:

- Top Bar:** A row of blue icons representing various functions: three bars, a blue diamond, a blue square with 'DFC', a circular arrow, a magnifying glass, a plus sign, a minus sign, a double-headed arrow, a 'VARS' button, and a 'X0 Y0' button.
- Left Column:** A vertical stack of icons for coordinate axes (Z, Y, X, X, Y, Z, Y) and a 'P' button.
- Workpiece Diagram:** A 2D diagram of a workpiece with a red box highlighting a specific area. A red arrow points from the text 'Different Start/Stop Position' to this area. Dimensions shown are 647.000 and 561.270.
- Toolpath:** A red line representing the toolpath, starting from a red circle and ending at a red triangle.
- Bottom Buttons:** A row of buttons for 'Jog over speed, [%]' (100, 120), 'Over Speed, [%]', 'Spindle Speed, [rpm]' (10000), 'Tool Length, [mm] 0.000', 'Tool T1', 'Z correction, mm 0.000', 'C-' (0), 'C+' (0), and a 'STOP' button.
- Log:** A text area showing error messages:
 - 11-17-44: Internal compilation error. Running stopped.
 - 11-17-44: DELTA\$\$\$\$=(0.000000,0.000000,10.000096,0.000000,0.000000,0.000000) in line (62)
 - 11-17-44: Internal compilation error. Running stopped.
 - 11-17-44: DELTA\$\$\$\$=(0.000000,0.000000,10.000096,0.000000,0.000000,0.000000) in line (62)
 - 11-17-44: Internal compilation error. Running stopped.
 - 11-18-12: Cannot run. Need to return to Toolpath: (-48.3385, 30.8144, -0.0000, 0.000000, 0.000000, 0.000000)
- Bottom Status:** Text fields for 'lib-shape-045.nc', 'MCC: Idle', 'C:', 'PLC: 0', 'I: 0', 'Cmd: 0 / 0 (9)', and a 'STOP' button.
- Right Column:** A vertical stack of icons for tool selection (T1-T4, T99) and coordinate axes (X, Y, Z, A) with their respective G54 values and current positions.

Option 2: Move back to stop position


The second option allows the operator to stop the machine, move the working tool to a desired position and then, after pressing the Run button, makes the machine automatically return to the original stopping position and resumes the cut from there. This is especially useful on large machines, where the operator may stop the machine in the middle of running the program to check the working tool and then has to move it closer in order to inspect it.

In order to set this option up, the user needs to select the particular axes for which the machine will check its position values and, if any of them are different from their position values at the stop point, the machine will move the working tool back in place. In the example below, axes x, y and z have been selected to go back to the original stopping point, therefor allowing the user to lift the tool and move it closer towards themselves, then pressing Run for the tool to move back:



The Lift Height has been set to be 15 mm, allowing the machine to lift the working tool before moving as to prevent any collision with the working part. Note that this value will be different depending on the specific part and machine configuration.

These two options can be set to be different for different axes - for example, the x- and y-axes can be set to return back to the original stopping point, while the z-axis can be set to block movement if the working tool has been moved up or down, as in the image below. Note however, that only one option is available for each specific axis.



Additional Notes

Start/stop can be performed via the 0xfffffff (Stop) and 0xfffffe (Start) commands. For instance,

```
gvarset(0xfffffff,1); //Stop Program
```

This can be used in procedures such as the HOMING_HANDLER Software PLC.

Additionally, the following global variables can be used:

GVAR_EXT_REFRESH_NC	100001	refresh nc program
GVAR_EXT_PLAYER_PLAY	100002	play
GVAR_EXT_RESET_NC	100003	reset nc program

Pause

As of December 2022, the myCNC firmware features the Pause functionality. This allows to:

- Adjust the Overspeed % to 0 (complete stop)
- Use the Pause button - action="player-pause" for pause/start

As opposed to the **Stop** button, which stop the program followed by the ability to start from the stop point, **Pause** is a smooth decrease in speed to zero without stopping the program execution.

Essentially, the **Pause** brings the base frequency to a halt. When the frequency is brought back up, the process continues. This makes the **Pause** resemble a "sleep" mode.

From:
<http://docs.pv-automation.com/> - **myCNC Online Documentation**



Permanent link:
<http://docs.pv-automation.com/quickstart/mycnc-quick-start/start-stop-setup>

Last update: **2022/11/30 16:20**