
Change IP Address of myCNC control board


1. Connect Host Computer with myCNC controller with USB cable.

2. Open Console window on Host Computer. If you have ARM (Odroid-C2/Raspberry/NanoPi-K2) Single Board Computer (SBC) purchased from us, click on **Terminal MATE** icon on Desktop



3. Run “minicom” software (for ARM(Odroid-C2)/Desktop Linux)

```
minicom -D /dev/ttyUSB0
```




4. Run command in terminal window to change IP address

```
#SLA 192 168 0 78
```


to change IP address to 192.168.0.78. Controller will reply

```
CMD: #SLA 192 168 0 78
```



5. If success, controller will reply with message

```
IP:  192.168.000.078
```



6. Close Terminal Window.

From:
http://cnc42.com/ - **myCNC Online Documentation**

Permanent link:
http://cnc42.com/mycnc/change_ip_address_of_mycnc_control_board?rev=1501187491

Last update: **2017/07/27 16:31**