
How to connect 24V NPN sensor to TTL input of CNC control board with optocouple



From:
http://cnc42.com/ - **myCNC Online Documentation**

Permanent link:
http://cnc42.com/other/npn-sensor-to-ttl-input?rev=1497820967

Last update: **2017/06/18 17:22**