# Triggers/Timers

Triggers

- To activate the trigger , it is necessary to check the box next to number of trigger:


- Then select the type of triggering the trigger.

- **_Faling Edge_** - Trigger triggering on the falling edge of the impulse, i.e. when passing from the upper state ("1") to the lower state ("0").

- **_Rising Edge_** - Trigger triggering on the rising edge of the impulse, i.e. when passing from the lower state ("0") to the upper state ("1").

- After tripping, you can select the controller's output

- You can also choose to start the necessary procedure for triggering the trigger

Timers

- To activate the timer , it is necessary to check the box next to number of timer:

- After activating the timer, it is necessary to select the operating output of the controller

- You must select the duration of the output pulse and the length of the pause. Values are set in ms:

Timer 0 schedule

Timer 1 schedule

From:
http://cnc42.com/ - **myCNC Online Documentation**

Permanent link:
http://cnc42.com/mycnc/triggers_and_timers?rev=1534513091

Last update: **2018/08/17 09:38**