














## Main window of the editor of control programs



### Cutting card management functions

	Selecting and opening a cutting layout for editing
	Saving the edited control program.
	Place the control program on the whole screen.
	Zoom in of the nesting chart
	Zoom out of the nesting chart
	Show dimensions of the nesting chart
	Show work area with nesting chart

**Editor Functions**

	Go to one line up the control program
	Go to one line down the control program
	Insert a new line. The insertion is performed above the selected row.
	Editing the selected line
	Cut the selected string to the new one.

From:

<http://cnc42.com/> - **myCNC Online Documentation**

Permanent link:

[http://cnc42.com/mycnc/mycnc\\_editor?rev=1527062386](http://cnc42.com/mycnc/mycnc_editor?rev=1527062386)Last update: **2018/05/23 03:59**