

myCNC Hardware

- [MyCNC EtherCAT Controller](#)
- [MyCNC-ET6 Controller](#)
 - [CNC kit 15PC-ET6R1-WP2](#)
- [MyCNC-ET10 Controller](#)
- [MyCNC-ET15 Controller](#)

[Change IP address of myCNC control board](#)

[Change IP address of Single Board Computer \(SBC\)](#)

[Change Screen Resolution for Single Board Computer \(SBC\)](#)

[HDMI event handler for SBC Tinkerboard](#)

[Teamviewer Reset Config](#)

[Open collector outputs and PWM outputs schematic design](#)

[Rotary encoder connection and setup](#)

[Wireless Pendants](#)

[Modbus Devices](#)

[Touchscreen Setup](#)

[MQL \(Minumum Quantity Lubrication\)](#)

[DC Motor Control](#)

[Mini PC](#)

From:

<http://docs.pv-automation.com/> - **myCNC Online Documentation**

Permanent link:

http://docs.pv-automation.com/mycnc/mycnc_hardware

Last update: **2025/12/16 13:30**

