

# myCNC Hardware

- [MyCNC-ET6 Controller](#)
  - [CNC kit 15PC-ET6R1-WP2](#)
- [MyCNC-ET7 Controller](#)
  - [CNC kit 15PC-ET7R2-WP1](#)
- [MyCNC-ET10 Controller](#)
- [MyCNC-ET15 Controller](#)

[Change IP address of myCNC control board](#)

[Change IP address of Single Board Computer \(SBC\)](#)

[Change Screen Resolution for Single Board Computer \(SBC\)](#)

[HDMI event handler for SBC Tinkerboard](#)

[Teamviewer Reset Config](#)

[Open collector outputs and PWM outputs schematic design](#)

[Rotary encoder connection and setup](#)

[Wireless Pendants](#)

[Modbus Devices](#)

[Touchscreen Setup](#)

[MQL \(Minumum Quantity Lubrication\)](#)

From:  
<http://cnc42.com/> - **myCNC Online Documentation**

Permanent link:  
[http://cnc42.com/mycnc/mycnc\\_hardware?rev=1582217622](http://cnc42.com/mycnc/mycnc_hardware?rev=1582217622)

Last update: **2020/02/20 11:53**

