






# Change Screen resolution for Single Board Computer (Odroid-C2)

- Open File Manager (operator's Home icon)
- Goto “/boot” or “devices/boot” folder (which is actually the same)







The screenshot shows a terminal window titled "Pluma (as superuser)" editing the file `*boot.ini`. The file contains configuration for the boot process, including setting the screen resolution using `setenv m` and `setenv m_bpp`. The current resolution is set to `1280x800p60hz`. The terminal output shows the following commands and their results:

```
# setenv m "1280x1024p60hz"
## --setenv m "1280x1024p60hz"

setenv m "1280x800p60hz"
## --setenv m "1280x800p60hz"

# setenv m "1280x768p60hz"
## --setenv m "1280x768p60hz"


# setenv m "1440x900p60hz"
## --setenv m "1600x900p60hz"
# setenv m "1600x900p60hz"


# setenv m "1600x1050p60hz"
# setenv m "1600x1200p60hz"
# setenv m "1920x1200p60hz"
# setenv m "2560x1080p60hz"
# setenv m "2560x1440p60hz"
# setenv m "2560x1600p60hz"
# setenv m "3440x1440p60hz"

# HDMI BPP Mode
setenv m_bpp "32"
# setenv m_bpp "24"
# setenv m_bpp "16"

# HDMI DVI/VGA modes
# By default it's set to HDMI, if needed change below.
# Document only a stable flag
```

The terminal window also shows the status bar with the file name `*boot.ini`, the current line and column (`Ln 82, Col 25`), and the input mode (`INS`).





From:  
<http://cnc42.com/> - myCNC Online Documentation

Permanent link:  
[http://cnc42.com/mycnc/change\\_screen\\_resolution\\_for\\_single\\_board\\_computer\\_sbc?rev=1511406647](http://cnc42.com/mycnc/change_screen_resolution_for_single_board_computer_sbc?rev=1511406647)

Last update: 2017/11/22 22:10

