

I/O expand cards mapping

This menu allows you to reassignment the input and output port on the controller, as well as connect the ports of the remote device connected to the modbus as input or output ports of the controller. Main window:



Basic functions:



• To create a rule, click the icon "add rules"

Mapping device		Device Id (Modbus)						urc	e poi	Destination port									
Not used	•	0				*	0			×	0			ŝ	A V	×			
5	÷																		
Input port #0	0	0	0	0	0	0	0	0	0	8	0	0	0	0	0	0	0	0	15
Input port #1	16	0	0	0	0	0	0	0	0	24	0	0	0	0	0	0	0	0	31
Input port #2	32	9	0	0	0	0	0	0	0	40	0	0	0	0	0	0	0	0	47
Input port #3	<mark>4</mark> 8	0	0	0	0	0	0	0	0	56	0	0	0	0	0	0	0	0	63
Input port #4	64	0	0	0	0	0	0	0	0	72	0	0	0	0	0	0	0	0	79
Input port #5	80	0	0	0	0	0	0	0	0	88	0	0	0	0	0	0	0	0	95
Input port #6	96	0	0	0	0	0	0	0	0	104	0	0	0	0	0	0	0	0	111
Input port #7	112	0	0	0	0	0	0	0	0	120	0	0	0	0	0	0	0	0	127
Input port #8	128	0	0	0	0	0	0	0	0	136	0	0	0	0	0	0	0	0	143
Input port #9	144	0	0	0	0	0	0	0	0	152	0	0	0	0	0	0	0	0	159
Output port #0	0	0	0	0	0	0	0	0	0	8	0	0	0	0	0	0	0	0	15
Output port #1	16	0	0	0	0	0	0	0	0	24	0	0	0	0	0	0	0	0	31
Output port #2	32	0	0	0	0	0	0	0	0	40	0	0	0	0	0	0	0	0	47
Output port #3	48	0	0	0	0	0	0	0	0	56	0	0	0	0	0	0	0	0	63

• Next, select the redirection conditions and the register for the mapping

Mapping device			rice odbu	_			50	urc	e por	De po		atio	n						
Not used	-	0				A V	0	_		*	0				*	×			
Not used																			
ET10 encoders inputs Modbus/Reg Inputs expansion Modbus/Reg Outputs expansion Modbus/Coil Input expansion Modbus/Coil Output expansion ETxx inputs	5	0 0	00	0 0	0 0	0 0	0 0	0 0	0 0	8 24	00	0 0	00	00	0 0	0 0	0 0	0 0	15 31
ETxx outputs	2	0	0	0	0	0	0	0	0	40	0	0	0	0	0	0	0	0	47
Input port #3	48	0	0	0	0	0	0	0	0	56	0	0	0	0	0	0	0	0	63
Input port #4	64	0	0	0	0	0	0	0	0	72	0	0	0	0	0	0	0	0	79
Input port #5	80	0	0	0	0	0	0	0	0	88	0	0	0	0	0	0	0	0	95
Input port #6	96	0	0	0	0	0	0	0	0	104	0	0	0	0	0	0	0	0	111
Input port #7	112	0	0	0	0	0	0	0	0	120	0	0	0	0	0	0	0	0	127
Input port #8	128	0	0	0	0	0	0	0	0	136	0	0	0	0	0	0	0	0	143
Input port #9	144	0	0	0	0	0	0	0	0	152	0	0	0	0	0	0	0	0	159
Output port #0	0	0	0	0	0	0	0	0	0	8	0	0	0	0	0	0	0	0	15
Output port #1	16	0	0	0	0	0	0	0	0	24	0	0	0	0	0	0	0	0	31
Output port #2	32	0	0	0	0	0	0	0	0	40	0	0	0	0	0	0	0	0	47
Output port #3	48	0	0	0	0	0	0	0	0	56	0	0	0	0	0	0	0	0	63

• After selecting the register for the mapping, the input or output register of the controller, where the selected registers will be redirected. An example is presented reassignment of the register of encoder inputs of the controller ET10 as a register of the controller's common inputs port 3

Mapping device ET 10 encoders inputs		Device Id (Modbus)					Source port				Destination port								
		0			×		0			-	3	3			*	×			
>	-																		
Input port #0	0	0	•	0	0	0	0	0	0	8	•	0	0	0	0	0	•	0	15
Input port #1	16	0	0	0		0	0	0	0	24	0	0	0	0	0	0	0	0	31
Input port #2	32	0	0	0	0	0	0	0	0	40	0	0	0	0	0	0	0	0	47
Input port #3	48	0	0	0	0	0	0	0	0	56	0	0	0	0	0	0	0	0	63
Input port #4	64	0	0	0	0	0	0	0	0	72	0	0	0	0	0	0	0	0	79
Input port #5	80	0	0	0	0	0	0	0	0	88	0	0	0	0	0	0	0	0	95

• This example shows how to connect an external controller to the modbus interface. At the remote controller with id = 1 input port number 2 (inputs from 32 to 47) is pushed to the input virtual port of controller number 3 (inputs from 48 to 63). The LED layouts below show the state of the port for each of the inputs.

Manning dowico		Device Id (Modbus)						Source port					Destination port									
Modbus/Reg Inputs expansion	•	1				A V	2			×	3				*	×						
5	þ																					
Input port #0	0	0	0	0	0	0	0	0	0	8	0	0	0	0	0	0	0	0	1			
Input port #1	16	0	0	0	0	0	0	0	0	24	0	0	0	0	0	0	0	0	3			
Input port #2	32	0	0	0	0	0	0	0	0	40	0	0	0	0	0	0	0	0	4			
Input port #3	48	0	0	0	0	0	0	0	0	56	0	0	0	0	0	0	0	0	6			

From: http://cnc42.com/ - myCNC Online Documentation

Permanent link: http://cnc42.com/mycnc/i_o_expand_cards_mapping?rev=1537532064



Last update: 2018/09/21 08:14